取 扱 説 明 書


OPERATOR'S MANUAL

WELLTRIS TM

WELLTRISIM
TM AND (C) 1989 DOKA. WELLTRIS ILCENSED TO BULLET-PROOF SOFTWARE.
(C) 1990 BULLET-PROOF SOFTWARE ALL RIGHTS RESERVED.
SUBLICENSED TO VIDEO SYSTEM CO.,LTD.

ORIGINAL CONCEPT AND DESIGN BY ALEXEY PAJITNOV


使用電源	DC+5V DC+12V			
Power Supply				
CRT画面	横 画 面			
Monitor	horizontal			
ゲームスタイル	IP、2P同時プレイ可			
Game Style	1 player Or 2 player Simultaneous			



Connector Diagram


●JAMMA規格

SOLDER SIDE(半田面)	NO.	NO.	PARTS SIDE (部品面)
GND	A	1	GND
GND	В	2	GND
+5V	С	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	Н	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	К	9	
SPEAKER (-)	L	10	SPEAKER (+)
	М	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	Р	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN SW 2	Т	16	COIN SW 1
2P START	U	17	1P START
2P UP	٧	18	1P UP
2P DOWN	W.	19	1P DOWN
2P LEFT	Х	20	1P LEFT
2P RIGHT	Υ	21	1P RIGHT
2P SW 1 A BUTTON	Z	22	1P SW 1 A BUTTON
2P SW 2 B BUTTON	а	23	1P SW 2 B BUTTON
	b	24	1
	С	25	
	d	26	
GND	е	27	GND
GND	f	28	GND



コントロールパネル Control Panel.

ジョイスティックレバー 8方向(2方向にもできます。) JOYSTICK LEVER……8 directions (or 2 directions)



DIP SW 1 (SW 2)

COIN 1							COI	N 2	
COIN/CREDIT		1	2	3	4	5	6	7	8
1COIN	1CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1COIN	2CREDITS	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
1COIN	3CREDITS	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
1COIN	4CREDITS	ON	ON	OFF	OFF	ON	ON	OFF	OFF
1COIN	5CREDITS	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
1COIN	6CREDITS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2COINS	1CREDIT	OFF	ON	ON	OFF	OFF	ON	ON	OFF
SCOINS	1CREDIT	ON	ON	ON	OFF	ON	ON	ON	OFF
COINS	1CREDIT	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
5COINS	1CREDIT	ON	OFF	OFF	ON	ON	OFF	OFF	ON
2COINS	3CREDITS	OFF	ON	OFF	ON	OFF	ON	OFF	ON
2COINS	1CREDIT								
4COINS	2CREDITS	ON	NO NO	OFF	ОИ	ON	ON	OFF	ОИ
5COINS	3CREDITS	ON							
6COINS	4CREDITS								
2COINS	1CREDIT	OFF	OFF	ON	ON	OFF	OFF	ON	ON
4COINS	3CREDITS	011	011	0.1			01.	0.1	0.1
1COIN	1CREDIT								
2COINS	2CREDITS								
3COINS	3CREDITS	ON	OFF	ON	ON	ON	OFF	ON	ОИ
4COINS	4CREDITS								
5COINS	6CREDITS								
1COIN	1CREDIT								
2COINS	2CREDITS	055	011	011	0.11	055	011	011	011
3COINS	3CREDITS	OFF	ON	ON	ON	OFF	ON	ON	ON
4COINS	5CREDITS								
COIN	1CREDIT	ON	ON	ON	ON	ON	ON	ON	ON
2COINS	3CREDITS	511	011	511	٥.,		J.,	J.,	011

DIP SW 2 (SW 3)

DI	P 2	1	2	3	4	5	6	7	8
DIFFICULTY	NORMAL EASY HARD SUPER HARD	OFF OFF ON ON	OFF ON OFF ON						
	1 COIN…1 PLAYER 2 COIN…2 PLAYER			OFF					
	1 COIN····1 or 2 PLAYER			ON					
DEMO SOUND	ON OFF				OFF				
N.C. OFF T	使用してください					OFF ON			
N.C. OFF	使用してください						OFF ON		
FLIP FLOP	OFF ON							OFF ON	
TEST MODE	OFF ON								OFF ON

※(SW__) は基板の方に入っているシルクのNOです。

Numbers shown as (SW__) are silk-printed on the substrate.

HOW TO PLAY


- ◆底面で縦、横のラインが揃えば消えます。
- ◆例面にはみ出ると、その分だけボーダーラインがせまってきます。
- ◆ブロックがボーダーラインに達すると、ゲームオーバーです。
- ◆ラインを消した数だけボーダーラインが元 にもどります。
- ◆ボーナスブロックを消せば復活!

- If blocks are aligned horizontally or vertically along the bottom surface, the entire line disappears.
- If a block protrudes into a wall, the border will close in.
- The border will recede backward as many lines as you delete.
- ◆If the blocks are piled high enough to reach the border, it is game-over.
- If you delete a bonus block, you gain a chance for a quick victory.


画面調整について

WHITE RED


GREEN **BLUE**



色あいを合わせます。 Rレベル、Gレベル、Bレベルを調整。



画面の縦横比をあわせます。 H-SIZE, V-SIZEを調整。



画面の位置を合わせます。

上下位置: V-POSI 左右位置:H-POSI

大きさ(はみ出しているかどうか):H-SIZE, V-SIZE

本 社 〒606 京都市左京区下鴨松ノ木町35-1 OFFICE: 35-1 Mathunoki-cho, Simogamo, Sakyo-ku, Kyoto, 606 Japan ■TEL/075-723-0358∜ ■FAX/075-723-0368